

Commercial Chase Bracket

»» Installation Instructions

Bracket can be fastened to vent or stack pipe with stainless steel band. Although not necessary, additional band can be used in the slot provided to secure bracket to vertical pipe. Bracket can also be secured to any flat surface with approved hardware using two mounting holes provided.

INSTALLATION

Position horizontal piping in the bracket to cradle the water header then solder copper pipe to the bracket. Heat the pipe, not the bracket.

Maximum load is 275 lbs.

Optional installation allows installer to secure water header by using a stainless band or cable tie threaded through horizontal slot then secure band or tie around water header and through the front channel of the bracket.



⚠ WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov

Patent # D 558,567
Made in USA
#IS-521-723 – 9/18

Supply

Drainage

Support

Specialties

www.siouxchief.com

14940 Thunderbird Road
Kansas City, MO 64147
P 1.800.821.3944
F 1.800.758.5950

