


»» DoubleDuty™ Test Plug Installation

To Perform DWV Pressure Test:




1. Unscrew and remove drain head. Keep head for later installation.


Note: Be sure to check with and follow all local plumbing codes during installation and testing of drain.

Lubricate O-Ring

Use silicone stem lube, lip balm, liquid soap, etc.




3. Set drain body to subfloor and solvent weld to drain piping per typical installation procedures.



2. Align lugs on test plug (just above O-Ring) with slots in clamping collar. Push plug through collar.


Thread plug into collar until O-Ring contacts pipe stop, Then give 1 Full turn only. Do not over-tighten.



4. Perform DWV pressure test. Plug can remain in place, to prevent loss or damage to drain head and to keep debris out of the drain line.


»» DoubleDuty™ Test Plug Installation

To Perform Shower Pan Test:




5. Remove test plug from collar and remove clamping collar and bolts.

Note: Be sure to check with and follow all local plumbing codes during installation and testing of drain.



7. Align lugs on test plug (just above O-Ring) with slots in clamping collar. Push plug through collar.


Thread plug into collar until O-Ring contacts pipe stop, then give 1 full turn only. Do not over-tighten.



6. Install waterproofing membrane under clamping collar per typical installation procedures.

Lubricate O-Ring

Use silicone stem lube, lip balm, liquid soap, etc.



8. Fill shower pan and perform shower pan test. When test is complete, replace test plug with drain head or plug can remain in place until tile installation.

14940 Thunderbird Road
Kansas City, Missouri 64147
P 1.800.821.3944
F 1.800.758.5950

#IS-821-TP DOUBLEDUTY INSTRUCTION SHEET - 7/17