
PlumbPerfect[®]

>> Nylon Closet Bolt


- 1. Preload bolts to the closet flange.
- 2. Place wax ring on the closet flange (most preferred) or on underside of bowl.
- 3. Set bowl over bolts, flange and wax ring.
- **4.** Push down on bowl until the wax gasket compresses, making sure the bowl's rim contacts the floor.
- Place cover cap-lock washer over bolt (correct side up). Cover cap-lock washers come with new tank/bowl combos or can be purchased separately.



Thread nuts onto bolts until hand tight.



Tighten nuts with ½" nut driver 1 to 2 full turns.



Cut off excess bolts and snap on cover cap.

#IS-425 PlumbPerfect - 9/18

Supply

Drainage

Support

Specialties

www.siouxchief.com

