

Add-A-Line™

Full-Slip Valve Tee Installation Guide






Before installation, consult local and jurisdictional plumbing codes.

Always install per local codes, using proper plumbing methods. Test all connections before use.

Failure to follow these instructions could result in personal injury or property damage

NOTE: The Add-A-Line™ is designed for use on copper supply lines only. Always wear gloves and safety glasses.

- 1: Shut off the water supply to the supply line where the valve will be installed.
- 2: With a permanent marker, mark the supply line at either end of the brass thread fittings.
- 3: Using a tube cutter, cut out a 1" section of the supply line between the inner marks.
- 4: Load the nut and ferrule over each section of supply line. Center the Add-A-Line over the opening, using the outer marks as a guide.
- 5: Orient the valve as needed and hand-tighten each nut on the valve trunk. Using one wrench to hold the trunk, tighten the nuts an additional 1 to 2 turns with a second wrench until tight. **Do Not Overtighten.**
- 6: Load the nut and ferrule over the outlet tubing, with the narrow end of the ferrule towards the valve.
- 7: Make sure the outlet tubing is inserted completely into the valve outlet and hand-tighten the nut. Using one wrench to hold the valve body, tighten the nut an additional 1 to 2 turns with a second wrench until tight. **Do Not Overtighten.**
- 8: Turn on water supply to supply line and check for leaks.



⚠ **WARNING:** Cancer and Reproductive Harm. www.P65Warnings.ca.gov

Supply

Drainage

Support

Specialties

www.siouxchief.com

TAKE THE FIELD.

